

CT66LWBIIF



33.5" x 23.63" x 23.5" (H x W x D)

Built-in undercounter refrigerator-freezer for general purpose use, w/dual evaporator cooling, lock, integrated door frame for overlay panels, white cabinet

Highlights:

Factory installed lock provides security you can count on

Flexible design allows built-in or freestanding use in 24" spaces

Customizable door front accepts full overlay panels for a seamless look that can blend into cabinetry

Product Features:

Slim undercounter dimensions	Less than 24 inches wide to fit tight spaces
Factory installed lock	Keyed lock offers added security
Built-in capable	Front-breathing design lets you make the best use of space by installing your appliance under the counter
Fully finished white cabinet	Allows the unit to be used freestanding
Height Adjustable	Adjustable legs allow the unit to be sized from 33 1/2" to 34 3/4" high
Integrated door frame	Customize the front by mounting an overlay panel over the door; seamless look can blend into other cabinetry with no exposed frame. Handle not included (panel size: 23 5/16" W x 28 1/4" H and at least 3/4" thick; maximum weight: 10 lbs.)
Cycle defrost	This system utilizes user-friendly automatic defrost operation in the fresh food section and efficient manual defrost operation in the freezer compartment
Dual evaporator cooling	Our unique and efficient design separately cools the refrigerator while maintaining a lower temperature in the freezer compartment by utilizing two evaporators
Adjustable shelves	Rearrange the refrigerator space to fit any sized item or remove shelves for simple cleanup

CT66LWBIIF Specifications:

Overview	
Nominal Height	34.0" (86 cm)
Height of Cabinet	33.5" (85 cm)
Nominal Width	24.0" (61 cm)
Width	23.63" (60 cm)
Nominal Depth	24.0" (61 cm)
Depth	23.5" (60 cm)
Depth with door at 90°	45.13" (115 cm)
Capacity	5.1 cu.ft. (144 L)
Defrost Type	Cycle
Door	Panel-Ready
Cabinet	White
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Amps	1.4
Voltage/Frequency	115 V AC/60 Hz
Weight	100.0 lbs. (45 kg)
Parts & Labor Warranty	1 Year
Compressor Warranty	5 Years
UPC	761101068848
Refrigerator-Freezer	
Door Swing	RHD
Reversible	Factory Reversible
Adjustable Shelves	Yes
Crisper Qty	1
Crisper Finish	Transparent
Crisper Cover	Glass
Interior Light	Yes
Refrigerator - Interior Height	19.5" (50 cm)
Refrigerator - Interior Width	20.5" (52 cm)
Refrigerator - Interior Depth	17.0" (43 cm)
Refrigerator - Shelf Type	Wire
Refrigerator - Shelf Qty	2
Refrigerator - Full Door Shelves	3
Freezer - Interior Height	5.0" (13 cm)
Freezer - Interior Width	19.0" (48 cm)

Freezer - Interior Depth	11.5" (29 cm)
Thermostat Type	Dial
Fan Type	Exterior
Refrigerant Type	R600a
Refrigerant Amount	0.92 oz.
High Side PSI	180.0
Low Side PSI	80.0
Level Legs	4
Compressor Step Height	7.0" (18 cm)
Compressor Step Width	20.5" (52 cm)
Compressor Step Depth	5.0" (13 cm)

