

CT66LWBISSTB



33.5" x 23.63" x 23.5" (H x W x D)

Built-in undercounter refrigerator-freezer for general purpose use, with lock, dual evaporator cooling, cycle defrost, SS door, TB handle and white cabinet

Highlights:

- Flexible design allows built-in or freestanding use in 24" spaces
- Factory installed lock provides security you can count on
- Stainless steel door with curved towel bar handle for added luxury

Product Features:

Slim undercounter dimensions	Less than 24 inches wide to fit tight spaces
Factory installed lock	Keyed lock offers added security
Built-in capable	Make the best use of space by installing your appliance under the counter and flush with other cabinetry
Fully finished white cabinet	Allows the unit to be used freestanding
Height Adjustable	Adjustable legs allow the unit to be sized from 33 1/2" to 34 3/4" high
Stainless steel wrapped door	Durable design with lasting elegance
Professional towel bar handle	Curved handle in brushed stainless steel offers a sturdy grip with professional elegance
Cycle defrost	This system utilizes user-friendly automatic defrost operation in the fresh food section and efficient manual defrost operation in the freezer compartment
Dual evaporator cooling	Our unique and efficient design separately cools the refrigerator while maintaining a lower temperature in the freezer compartment by utilizing two evaporators

CT66LWBISSTB Specifications:

Overview	
Nominal Height	34.0" (86 cm)
Height of Cabinet	33.5" (85 cm)
Nominal Width	24.0" (61 cm)
Width	23.63" (60 cm)
Nominal Depth	24.0" (61 cm)
Depth	23.5" (60 cm)
Depth with Handle	25.63" (65 cm)
Depth with door at 90°	45.63" (116 cm)
Capacity	5.1 cu.ft. (144 L)
Defrost Type	Cycle
Door	Stainless Steel
Cabinet	White
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Amps	1.4
Voltage/Frequency	115 V AC/60 Hz
Weight	100.0 lbs. (45 kg)
Parts & Labor Warranty	1 Year
Compressor Warranty	5 Years
UPC	761101068909
Refrigerator-Freezer	
Door Swing	RHD
Reversible	Factory Reversible
Adjustable Shelves	Yes
Crisper Qty	1
Crisper Finish	Transparent
Crisper Cover	Glass
Interior Light	Yes
Refrigerator - Interior Height	19.5" (50 cm)
Refrigerator - Interior Width	20.5" (52 cm)
Refrigerator - Interior Depth	17.0" (43 cm)
Refrigerator - Shelf Type	Wire
Refrigerator - Shelf Qty	2
Refrigerator - Full Door Shelves	3
Freezer - Interior Height	5.0" (13 cm)

Freezer - Interior Width	19.0" (48 cm)
Freezer - Interior Depth	11.5" (29 cm)
Thermostat Type	Dial
Fan Type	Exterior
Refrigerant Type	R600a
Refrigerant Amount	0.92 oz.
High Side PSI	180.0
Low Side PSI	80.0
Level Legs	4
Compressor Step Height	7.0" (18 cm)
Compressor Step Width	20.5" (52 cm)
Compressor Step Depth	5.0" (13 cm)

