

# ADA404REFSSHVLHD



32" x 20.88" x 23" (H x W x D)

Built-in undercounter ADA compliant +2°C to +8°C all-refrigerator with white cabinet and stainless steel door and handle, factory-installed lock, digital controls, wire shelving, hospital cord with 'green dot' plug, and automatic defrost operation

**Highlights:**

Just 32" high for an easy fit under lower ADA compliant counters

Flexible design allows built-in or freestanding use in 21" wide spaces

Wire shelving offers convenient storage of a variety of items

**Product Features:**

20" Wide Built-In Healthcare All-Refrigerator, Slim-fitting all-refrigerator for general healthcare applications at an ADA-compliant height ADA-Compliant	
Built-In Capable	Front-breathing design lets you make the best use of space by installing your appliance under the counter
ADA-Compliant Design	32" height allows easy installation under lower ADA compliant counters
Stainless Steel Wrapped Door	Durable and stylish design with lasting elegance
Professional Stainless Steel Handle	Thin (14mm diameter) stainless steel handle mounted vertically for a sleek look that matches many popular styles of cabinetry
2 to 8°C Operation	Designed to safely store select pharmaceuticals and other materials with strict temperature requirements
Automatic Defrost	Reduced user maintenance with an auto defrost system
Access Port	Unit comes with a factory installed probe hole for users to connect their own monitoring equipment
Factory-Installed Lock	Located towards the top of the door for easy access and to provide added security of unit (2 keys included)

## ADA404REFSSHVLHD Specifications:

Overview	
Nominal Height	32.0" (81 cm)
Height of Cabinet	31.75" (81 cm)
Height to Hinge Cap	32.0" (81 cm)
Nominal Width	21.0" (53 cm)
Width	20.88" (53 cm)
Nominal Depth	23.0" (58 cm)
Depth	23.0" (58 cm)
Depth with Handle	25.0" (64 cm)
Depth with door at 90°	40.25" (102 cm)
Capacity	3.32 cu.ft. (94 L)
Defrost Type	Automatic
Door	Stainless Steel
Cabinet	White
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Amps	1.1
Voltage/Frequency	115 V AC/60 Hz
Weight	85.0 lbs. (39 kg)
Parts & Labor Warranty	1 Year
Compressor Warranty	5 Years
UPC	761101151342

Refrigerator Features	
Door Swing	LHD
Reversible	Yes
Height Adjustable	No
Shelf Type	Wire
Adjustable Shelves	Yes
Thermostat Type	Digital
Fan Type	Interior
Refrigerant Type	R600a
Refrigerant Amount	0.99oz.
High Side PSI	180.0
Low Side PSI	80.0
Level Legs Qty	4
Interior Light	Yes
Temperature Range	2 to 8°C

Dimensions	
Interior Height	23.5" (60 cm)

Interior Width	16.25" (41 cm)
Interior Depth	17.0" (43 cm)
Compressor Step Height	6.25" (16 cm)
Compressor Step Width	16.25" (41 cm)
Compressor Step Depth	6.0" (15 cm)

