

AFS17PVMCLHD



79.5" x 27.5" x 26.63" (H x W x D)

Performance series 14.83 cu. ft. upright frost-free MOMCUBE freezer purpose-built for breast milk storage

Highlights:

Purpose-built for environments complying with Section 4207 of the Patient Protection and Affordable Care Act

Designed for storing breast milk in NICUs, hospitals, maternity wards, lactation rooms, mothers' suites, and other facilities

Intelligent microprocessor digital temperature controller

Product Features:

Performance MOMCUBE Breast Milk FreezerPurpose-built Performance Series freezer for the long-term storage of breast milk freezer

Purpose-built design	Designed and purpose-built for breast milk storage in accordance with the CDC's guidelines
Spacious capacity	Over 14.5 cu.ft. of storage inside
Frost-free operation	No-frost operation for minimal user maintenance
+/-1°C Variation	The published temperature variation is derived from the maximum deviation of an NTC sensor in a 1 oz. vial located nearest the chamber geometric center during a 24 hour test period
Microprocessor control panel	Digital controls with a large LED readout in Celsius or Fahrenheit for intuitive temperature management
Adjustable temperature	Intuitive controls let you adjust the interior temperature between -30°C to -10°C
High/low temperature alarm	Visual and audible alarms alert if the interior temperature rises or falls out of set range
Remote alarm contacts	Electronic controller is equipped with a volt-free contact for alarm forwarding to an external remote system (contacts located in the external rear of the unit)

AFS17PVMCLHD Specifications:

Overview	
Nominal Height	80.0" (203 cm)
Height of Cabinet	79.5" (202 cm)
Nominal Width	28.0" (71 cm)
Width	27.5" (70 cm)
Width with Door Open	27.75" (70 cm)
Nominal Depth	27.0" (69 cm)
Depth	26.63" (68 cm)
Depth with Handle	28.13" (71 cm)
Depth with door at 90°	54.75" (139 cm)
Capacity	14.83 cu.ft. (420 L)
Defrost Type	Frost-Free
Door	White
Cabinet	White
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Amps	4.3
Voltage/Frequency	115 V AC/60 Hz
Parts & Labor Warranty	2 Years
Compressor Warranty	5 Years
UPC	761101152387
Freezer	
Door Swing	LHD
Interior Height	49.0" (124 cm)
Interior Width	19.25" (49 cm)
Interior Depth	18.0" (46 cm)
Shelf Type	Wire
Shelf Qty	6
Adjustable Shelves	Yes
Thermostat Type	Digital
Interior Light	Yes
Fan Type	Interior
Refrigerant Type	R290a
Refrigerant Amount	3.27 oz.
High Side PSI	280.0
Low Side PSI	130.0
Wheels	4
Compressor Step Height	10.0" (25 cm)

Compressor Step Width	19.25" (49 cm)
Compressor Step Depth	16.0" (41 cm)
Temperature Range	-30 to -10°C

