



ALR47B



32" x 19.75" x 22.5" (H x W x D)

Built-in undercounter ADA compliant residential all-refrigerator in black with door storage and automatic defrost operation

Highlights:

- Just 32" high for an easy fit under lower ADA compliant counters
- Flexible design allows built-in or freestanding use in 20" wide spaces
- Adjustable glass shelving and door racks offer convenient storage for a variety of items

Product Features:

ADA compliant design	32" height allows easy installation under lower ADA compliant counters
Built-in capable	Front-breathing design lets you make the best use of space by installing your appliance under the counter
Adjustable thermostat	Digital thermostat offers easy temperature management with a readout in Fahrenheit or Celsius
Door shelves	Three removable door racks for additional storage of larger items
Adjustable glass shelves	Three adjustable spill-proof shelves for optimal storage in 3.53 cu. ft. interior
Fruit and vegetable crisper	Get the longest life and best taste out of produce by storing greens in a convenient slide drawer
Reversible door	User-reversible door swing for added flexibility to best accommodate your setting
3" thick door	Improved insulation for an efficient performance; NOTE: due to the oversized design, the door does not open in its own radius. If installing this refrigerator against a wall, please see our drawings to ensure adequate space
Temperature alarms	User-set high/low temperature alarms provide added security if temperature goes beyond setpoint



ALR47B Specifications:

Overview	
Nominal Height	32.0" (81 cm)
Height of Cabinet	31.75" (81 cm)
Height to Hinge Cap	32.0" (81 cm)
Nominal Width	20.0" (51 cm)
Width	19.75" (50 cm)
Width with Door Open	20.25" (51 cm)
Nominal Depth	23.0" (58 cm)
Depth	22.5" (57 cm)
Depth with Handle	24.38" (62 cm)
Depth with door at 90°	40.25" (102 cm)
Capacity	3.53 cu.ft. (100 L)
Defrost Type	Automatic
Door	Black
Cabinet	Black
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Energy Usage/Year	251.0kWh/year
Amps	1.1
Voltage/Frequency	115 V AC/60 Hz
Weight	65.0 lbs. (29 kg)
Parts & Labor Warranty	1 Year
Compressor Warranty	5 Years
UPC	761101073996
Refrigerator Features	
Door Swing	RHD
Reversible	Yes
Crisper Qty	1
Crisper Finish	Transparent
Crisper Cover	Glass
Shelf Type	Glass
Shelf Qty	3
Full Door Shelf Qty	3
Adjustable Shelves	Yes
Thermostat Type	Digital
Fan Type	Interior
Refrigerant Type	R600a
Refrigerant Amount	0.99oz.

High Side PSI	180.0
Low Side PSI	80.0
Level Legs Qty	2
Wheel Qty	2
Interior Light	Yes
Temperature Range	35 to 46°F
Sound Level	33.2 dB
Dimensions	
Interior Height	23.5" (60 cm)
Interior Width	16.25" (41 cm)
Interior Depth	17.0" (43 cm)
Compressor Step Height	6.25" (16 cm)
Compressor Step Width	16.25" (41 cm)
Compressor Step Depth	6.0" (15 cm)

