



BRF631BKYADA



32.38" x 23.63" x 23" (H x W x D)

24 in. wide ADA height refrigerator-freezer for residential use with a saffron gold door, stainless steel handle, and black cabinet

Highlights:

- Saffron gold door finish brightens up your kitchen space
- 32" height for use in ADA compliant settings
- Over 5 cu.ft. of storage capacity in a perfectly sized 24" footprint

Product Features:

24" wide European refrigerator-freezer	Designed for freestanding or recessed installation in 24" wide spaces
ENERGY STAR certified	Rated by the DOE to perform with more efficiency than federal standards require, saving your unit energy and you on higher utility costs
ADA compliant design	32" height for use in settings complying with ADA guidelines for lower counter height
Slim counter height dimensions	Ideal 24" footprint offers full 5.1 cu.ft. storage capacity in a slim fit
Saffron gold door	Bright yellow door finish with a slight gloss to elevate your undercounter space
Professional handle	Brushed stainless steel handle with a thin 14mm diameter is mounted horizontally across the door for a sleek look
Cycle defrost	This system utilizes user-friendly automatic defrost operation in the fresh food section and efficient manual defrost operation in the freezer compartment
Dual evaporator cooling	Our unique and efficient design separately cools the refrigerator while maintaining a lower temperature in the freezer compartment by utilizing two evaporators
Adjustable glass shelves	Rearrange the refrigerator space to fit any sized item or remove shelves for simple cleanup



BRF631BKYADA Specifications:

Overview

Nominal Height	32.0" (81 cm)
Height of Cabinet	32.13" (82 cm)
Height to Hinge Cap	32.38" (82 cm)
Nominal Width	24.0" (61 cm)
Width	23.63" (60 cm)
Nominal Depth	23.0" (58 cm)
Depth	23.0" (58 cm)
Depth with Handle	24.5" (62 cm)
Depth with door at 90°	45.25" (115 cm)
Capacity	5.1 cu.ft. (144 L)
Defrost Type	Cycle
Door	Yellow
Cabinet	Black
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Energy Usage/Year	330.0kWh/year
Amps	1.2
Voltage/Frequency	115 V AC/60 Hz
Weight	110.0 lbs. (50 kg)
Parts & Labor Warranty	1 Year
Compressor Warranty	5 Years
UPC	761101087801

Refrigerator-Freezer

Door Swing	RHD
Reversible	Yes
Adjustable Shelves	Yes
Crisper Qty	1
Crisper Finish	Transparent
Crisper Cover	Glass
Wine Bottle Shelving	Yes
Interior Light	Yes
Refrigerator - Interior Height	18.0" (46 cm)
Refrigerator - Interior Width	21.0" (53 cm)
Refrigerator - Interior Depth	18.0" (46 cm)
Refrigerator - Capacity	4.5 cu.ft
Refrigerator - Shelf Type	Glass
Refrigerator - Shelf Qty	2

Refrigerator - Full Door Shelves	3
Freezer - Interior Height	5.25" (13 cm)
Freezer - Interior Width	19.0" (48 cm)
Freezer - Interior Depth	11.5" (29 cm)
Freezer - Capacity	0.6 cu.ft
Thermostat Type	Dial
Refrigerant Type	R600a
Refrigerant Amount	0.92 oz.
High Side PSI	180.0
Low Side PSI	80.0
Compressor Step Height	5.5" (14 cm)
Compressor Step Width	21.0" (53 cm)
Compressor Step Depth	6.0" (15 cm)

