



CM42PL



32.63" x 18.88" x 19.88" (H x W x D)

19" wide counter height manual defrost refrigerator-freezer in a stainless steel look

Highlights:

- Made in Europe
- Compact size with a slim 19" width fits well in small kitchens, hotels and offices
- Adjustable wire shelf, three door racks, and large crisper drawer for optimum storage

Product Features:

19" Wide Compact Refrigerator-Freezer	Slim-fitting refrigerator with freezer compartment for easy storage in hospitality settings
Stainless steel look	Unit has a stainless steel-like silver finish with a vertical grain on the door
Manual defrost	Static cooling system with no fans or warming cycles
Freezer compartment	Interior freezer compartment offers convenient storage for ice packs and ice cubes
Adjustable wire shelf	Rearrange the refrigerator space to fit any sized item or remove wire shelf for simple cleanup
Adjustable thermostat	Dial thermostat located inside for easy temperature management
Summer/Winter function	Enhances cooling performance year-round, adjusting operation for hot or cold environments to ensure consistent and optimal refrigeration and freezing
SuperFreeze function	This setting is ideal for freezing fresh foods quickly. Function overrides current thermostat controls to ensure compressor operates continuously
Crisper drawer	Removable clear drawer ideal for organizing non-perishable items



CM42PL Specifications:

Overview	
Height of Cabinet	32.25" (82 cm)
Height to Hinge Cap	32.63" (83 cm)
Width	18.88" (48 cm)
Depth	19.88" (50 cm)
Depth with door at 90°	39.75" (101 cm)
Capacity	3.1 cu.ft. (88 L)
Defrost Type	Manual
Door	Stainless Look
Cabinet	Stainless Look
US Electrical Safety	UL
Canadian Electrical Safety	ULC
Energy Usage/Year	219.0kWh/year
Amps	1.06
Voltage/Frequency	115 V AC/60 Hz
Weight	49.0 lbs. (22 kg)
Parts & Labor Warranty	1 Year
Compressor Warranty	5 Years
UPC	761101146553
Refrigerator-Freezer	
Door Swing	RHD
Reversible	Yes
Adjustable Shelves	Yes
Crisper Qty	1
Crisper Finish	Transparent
Crisper Cover	Plastic
Interior Light	Yes
Refrigerator - Interior Height	27.0" (69 cm)
Refrigerator - Interior Width	15.75" (40 cm)
Refrigerator - Interior Depth	14.5" (37 cm)
Refrigerator - Shelf Type	Wire
Refrigerator - Shelf Qty	1
Refrigerator - Full Door Shelves	3
Can Storage	Yes
Freezer - Interior Height	5.0" (13 cm)
Freezer - Interior Width	15.75" (40 cm)

Freezer - Interior Depth	11.0" (28 cm)
Thermostat Type	Dial
Fan Type	Interior
Refrigerant Type	R600a
Refrigerant Amount	0.46 oz.
Compressor Step Height	7.5" (19 cm)
Compressor Step Width	15.75" (40 cm)
Compressor Step Depth	5.0" (13 cm)
Sound Level	32.3 dB

For a more detailed view of this unit's dimensions, view the "SPECIFICATIONS" table or download this unit's brochure.

