



# CT661WADA



32.38" x 23.63" x 23" (H x W x D)

ADA compliant ENERGY STAR certified refrigerator-freezer for residential use, cycle defrost with deluxe interior and white finish

**Highlights:**

ENERGY STAR certified for guaranteed savings and a greener performance

32" height for use in ADA compliant settings

Over 5 cu.ft. of storage capacity in a perfectly sized 24" footprint

**Product Features:**

24" Wide European ADA Height Refrigerator-Includes a full refrigerator and freezer section for undercounter use  
Freezer

|                                |                                                                                                                                                                 |
|--------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Peak24 Series                  | European-made collection for recessed installation featuring large capacity interiors, ENERGY STAR certified performances, and versatile style                  |
| ENERGY STAR certified          | Rated by the DOE to perform with more efficiency than federal standards require, saving your unit energy and you on higher utility costs                        |
| ADA Compliant                  | 32" height for recessed use in settings complying with ADA guidelines for lower counter height                                                                  |
| Slim counter height dimensions | Ideal 24" footprint offers full 5.1 cu.ft. storage capacity in a slim fit                                                                                       |
| Dual evaporator cooling        | Our unique and efficient design separately cools the refrigerator while maintaining a lower temperature in the freezer compartment by utilizing two evaporators |
| Cycle defrost                  | This system utilizes user-friendly automatic defrost operation in the fresh food section and efficient manual defrost operation in the freezer compartment      |
| Adjustable glass shelves       | Rearrange the refrigerator space to fit any sized item or remove shelves for simple cleanup                                                                     |
| Crisper drawer                 | Get the longest life and best taste out of produce by storing greens in lower slide drawer                                                                      |



CT661WADA Specifications:

| Overview                         |                    |
|----------------------------------|--------------------|
| Height of Cabinet                | 32.0" (81 cm)      |
| Height to Hinge Cap              | 32.38" (82 cm)     |
| Width                            | 23.63" (60 cm)     |
| Depth                            | 23.0" (58 cm)      |
| Depth with Handle                | 24.63" (63 cm)     |
| Depth with door at 90°           | 45.38" (115 cm)    |
| Capacity                         | 5.1 cu.ft. (144 L) |
| Defrost Type                     | Cycle              |
| Door                             | White              |
| Cabinet                          | White              |
| US Electrical Safety             | ETL                |
| Canadian Electrical Safety       | ETL-C              |
| Energy Usage/Year                | 365.0kWh/year      |
| Amps                             | 1.2                |
| Voltage/Frequency                | 115 V AC/60 Hz     |
| Weight                           | 100.0 lbs. (45 kg) |
| Parts & Labor Warranty           | 1 Year             |
| Compressor Warranty              | 5 Years            |
| UPC                              | 761101068275       |
| Refrigerator-Freezer             |                    |
| Door Swing                       | RHD                |
| Reversible                       | Yes                |
| Adjustable Shelves               | Yes                |
| Crisper Qty                      | 1                  |
| Crisper Finish                   | Transparent        |
| Crisper Cover                    | Glass              |
| Wine Bottle Shelving             | Yes                |
| Interior Light                   | Yes                |
| Refrigerator - Interior Height   | 18.0" (46 cm)      |
| Refrigerator - Interior Width    | 21.0" (53 cm)      |
| Refrigerator - Interior Depth    | 18.0" (46 cm)      |
| Refrigerator - Capacity          | 4.5 cu.ft          |
| Refrigerator - Shelf Type        | Glass              |
| Refrigerator - Shelf Qty         | 2                  |
| Refrigerator - Full Door Shelves | 3                  |
| Freezer - Interior Height        | 5.25" (13 cm)      |

|                          |               |
|--------------------------|---------------|
| Freezer - Interior Width | 19.0" (48 cm) |
| Freezer - Interior Depth | 11.5" (29 cm) |
| Freezer - Capacity       | 0.6 cu.ft     |
| Thermostat Type          | Dial          |
| Refrigerant Type         | R600a         |
| Refrigerant Amount       | 0.92 oz.      |
| High Side PSI            | 180.0         |
| Low Side PSI             | 80.0          |
| Compressor Step Height   | 5.5" (14 cm)  |
| Compressor Step Width    | 21.0" (53 cm) |
| Compressor Step Depth    | 6.0" (15 cm)  |

