



CT661WSSTBADA



32.38" x 23.63" x 23" (H x W x D)

24" wide residential ENERGY STAR certified 5 cu.ft. refrigerator-freezer made in Europe with a stainless steel door and white cabinet in an ADA compliant height

Highlights:

ENERGY STAR certified for guaranteed savings and a greener performance

32" height for use in ADA compliant settings

Over 5 cu.ft. of storage capacity in a perfectly sized 24" footprint

Product Features:

24" Wide European ADA Height Refrigerator-Includes a full refrigerator and freezer section for undercounter use
Freezer

| | |
|--------------------------------|---|
| Peak24 Series | European-made collection for recessed installation featuring large capacity interiors, ENERGY STAR certified performances, and versatile style |
| ENERGY STAR certified | Rated by the DOE to perform with more efficiency than federal standards require, saving your unit energy and you on higher utility costs |
| ADA compliant | 32" height for use in settings complying with ADA guidelines for lower counter height |
| Slim counter height dimensions | Ideal 24" footprint offers full 5.1 cu.ft. storage capacity in a slim fit |
| Stainless steel wrapped door | Durable 304 grade wrapping |
| Professional towel bar handle | Curved handle in brushed stainless steel offers a sturdy grip with professional elegance |
| Dual evaporator | Our unique and efficient design separately cools the refrigerator while maintaining a lower temperature in the freezer compartment by utilizing two evaporators |
| Cycle defrost | This system utilizes user-friendly automatic defrost operation in the fresh food section and efficient manual defrost operation in the freezer compartment |



CT661WSSTBADA Specifications:

| Overview | |
|--------------------------------|---------------------|
| Nominal Height | 32.0" (81 cm) |
| Height of Cabinet | 32.0" (81 cm) |
| Height to Hinge Cap | 32.38" (82 cm) |
| Nominal Width | 24.0" (61 cm) |
| Width | 23.63" (60 cm) |
| Nominal Depth | 23.0" (58 cm) |
| Depth | 23.0" (58 cm) |
| Depth with Handle | 25.25" (64 cm) |
| Depth with door at 90° | 45.38" (115 cm) |
| Capacity | 5.04 cu.ft. (143 L) |
| Defrost Type | Cycle |
| Door | Stainless Steel |
| Cabinet | White |
| US Electrical Safety | ETL |
| Canadian Electrical Safety | ETL-C |
| Energy Usage/Year | 330.0kWh/year |
| Amps | 1.2 |
| Voltage/Frequency | 115 V AC/60 Hz |
| Weight | 100.0 lbs. (45 kg) |
| Parts & Labor Warranty | 1 Year |
| Compressor Warranty | 5 Years |
| UPC | 761101068473 |
| Refrigerator-Freezer | |
| Door Swing | RHD |
| Reversible | Factory Reversible |
| Adjustable Shelves | Yes |
| Crisper Qty | 1 |
| Crisper Finish | Transparent |
| Crisper Cover | Glass |
| Wine Bottle Shelving | Yes |
| Interior Light | Yes |
| Refrigerator - Interior Height | 18.0" (46 cm) |
| Refrigerator - Interior Width | 21.0" (53 cm) |
| Refrigerator - Interior Depth | 18.0" (46 cm) |
| Refrigerator - Capacity | 4.5 cu.ft |

| | |
|----------------------------------|---------------|
| Refrigerator - Shelf Type | Glass |
| Refrigerator - Shelf Qty | 2 |
| Refrigerator - Full Door Shelves | 3 |
| Freezer - Interior Height | 5.25" (13 cm) |
| Freezer - Interior Width | 19.0" (48 cm) |
| Freezer - Interior Depth | 11.5" (29 cm) |
| Freezer - Capacity | 0.6 cu.ft |
| Thermostat Type | Dial |
| Refrigerant Type | R600a |
| Refrigerant Amount | 0.92 oz. |
| High Side PSI | 180.0 |
| Low Side PSI | 80.0 |
| Compressor Step Height | 5.5" (14 cm) |
| Compressor Step Width | 21.0" (53 cm) |
| Compressor Step Depth | 6.0" (15 cm) |

