



CT663BKBKBIKSHHADA



32.38" x 23.63" x 23.5" (H x W x D)

ADA compliant built-in undercounter refrigerator-freezer for residential use, cycle defrost w/deluxe interior, black stainless steel door, horizontal handle, and black cabinet

Highlights:

- 32" height fits under lower ADA compliant counters
- 304 grade stainless steel in a high gloss neutral finish from our basalt collection
- Fingerprint resistant door hides most smudges and is easy to clean with a dry cloth

Product Features:

ADA compliant	32" high to fit under lower ADA compliant counters
Slim undercounter dimensions	Less than 24" wide with a generous storage capacity
Built-in capable	Make the best use of space by installing your appliance under the counter
Black stainless steel wrapped door	304 grade stainless steel in a high gloss neutral finish from our basalt collection; note: due to the reflective quality of our door finish, this color may appear different under different lighting and surrounding conditions
Fingerprint resistant	Door wipes clean with a dry cloth, while the dark basalt finish hides most smudges
Professional horizontal handle	Brushed stainless steel handle with a thin 14mm diameter is mounted horizontally across the door for a sleek look
Cycle defrost	This system utilizes user-friendly automatic defrost operation in the fresh food section and efficient manual defrost operation in the freezer compartment
Dual evaporator	Our unique and efficient design separately cools the refrigerator while maintaining a lower temperature in the freezer compartment by utilizing two evaporators
Adjustable glass shelves	Rearrange refrigerator space to accommodate all sizes or remove shelves for simple cleanup



CT663BKBIKSHHADA Specifications:

Overview	
Nominal Height	32.0" (81 cm)
Height of Cabinet	32.0" (81 cm)
Height to Hinge Cap	32.38" (82 cm)
Nominal Width	24.0" (61 cm)
Width	23.63" (60 cm)
Nominal Depth	24.0" (61 cm)
Depth	23.5" (60 cm)
Depth with door at 90°	45.38" (115 cm)
Capacity	5.1 cu.ft. (144 L)
Defrost Type	Cycle
Door	Black Stainless Steel
Cabinet	Black
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Energy Usage/Year	365.0kWh/year
Amps	1.4
Voltage/Frequency	115 V AC/60 Hz
Weight	100.0 lbs. (45 kg)
Parts & Labor Warranty	1 Year
Compressor Warranty	5 Years
UPC	761101068572
Refrigerator-Freezer	
Door Swing	RHD
Reversible	Yes
Adjustable Shelves	Yes
Crisper Qty	1
Crisper Finish	Transparent
Crisper Cover	Glass
Wine Bottle Shelving	Yes
Interior Light	Yes
Refrigerator - Interior Height	18.0" (46 cm)
Refrigerator - Interior Width	21.0" (53 cm)
Refrigerator - Interior Depth	18.0" (46 cm)
Refrigerator - Capacity	4.5 cu.ft
Refrigerator - Shelf Type	Glass

Refrigerator - Shelf Qty	2
Refrigerator - Full Door Shelves	3
Freezer - Interior Height	5.25" (13 cm)
Freezer - Interior Width	19.0" (48 cm)
Freezer - Interior Depth	11.5" (29 cm)
Freezer - Capacity	0.6 cu.ft
Thermostat Type	Dial
Fan Type	Exterior
Refrigerant Type	R600a
Refrigerant Amount	0.92 oz.
High Side PSI	180.0
Low Side PSI	80.0
Level Legs	4
Compressor Step Height	5.5" (14 cm)
Compressor Step Width	21.0" (53 cm)
Compressor Step Depth	6.0" (15 cm)

