

N916

INDEPENDENT LAT PULLDOWN

The SportsArt Status Strength Series is our premium club line and combines sleek and modern design with world-class components and superior biomechanics to deliver unmatched quality and function to your facility.

KEY FEATURES

- Pivoting flex handles reduce joint stress and help prevent injury
- Biomechanically beneficial diverging motion
- Gas-assisted seat adjustment and adjustable thigh pads accommodate users of different sizes
- 2:1 ratio (1 hand) and 1:1 ratio (2 hands)



TECHNICAL DETAILS	
Unit Weight	484 lbs / 220 kg
Dimensions (LxWxH)	57.4 x 34.5 x 82.7 in / 145.8 x 90.1 x 210 cm
Weight Stack	220 lbs / 100 kg
Max User Weight	500 lbs / 227 kg
Features	<p>Strengthens back and core musculature</p> <p>Independent nature allows for unilateral or bilateral movement</p> <p>Pivoting handles follow the user to fit biomechanical needs and may decrease risk of shoulder injury</p> <p>Magnetized stack-fork with retracting tether makes for instant, secure selection of weights</p> <p>Cold rolled steel weight stacks with noise dampening</p> <p>Stainless steel guide rods resist rust and stay smooth</p> <p>Kevlar belts for quiet, smooth action and optimal tensile strength; belt contains 2200 lb (998 kg) tensile strength aircraft cables.</p> <p>Heavy-duty double-stitched upholstery</p> <p>Durable European-styled cushions</p>

WARRANTY*	
Type	Full Commercial - no usage limit
Frame	10 Years
Weights & Guide Rods	5 Years
Cables, Belts, Bearings & Parts	3 Years
Grips, Enclosures & Covers	1 Year
Upholstery	6 Months
Labor	1 Year

