

N919

INDEPENDENT LATERAL RAISE

The SportsArt Status Strength Series is our premium club line and combines sleek and modern design with world-class components and superior biomechanics to deliver unmatched quality and function to your facility.

KEY FEATURES

- Handles rotate naturally throughout the motion and reduce wrist stress
- Gas-assisted seat adjustment puts you in the proper position for action
- Foot rest helps maintain biomechanically correct exercise position
- Elbow pad increases stability and isolates lateral head of the deltoid
- Incremental 3.3 & 6.6 lbs (1.5 & 3 kg) micro-loading adjustment



TECHNICAL DETAILS

Unit Weight	488.4 lbs / 222 kg
Dimensions (LxWxH)	51.5 x 53.4 x 60.4 in / 130.7 x 135.5 x 153.5 cm
Weight Stack	132 lbs / 60 kg
Max User Weight	500 lbs / 227 kg
Starting Weight	7.7 lbs / 3.5 kg
Features	<p>Strengthens lateral deltoids</p> <p>Back support isolates deltoid muscles and ensures strict form</p> <p>Upright starting handle position helps to avoid shoulder impingement syndrome by keep wrists in a neutral position</p> <p>Magnetized stack-fork with retracting tether makes for instant, secure selection of weights</p> <p>Cold rolled steel weight stacks with noise dampening</p> <p>Stainless steel guide rods resist rust and stay smooth</p> <p>Kevlar belts for quiet, smooth action and optimal tensile strength; belt contains 2200 lb (998 kg) tensile strength aircraft cables.</p> <p>Heavy-duty double-stitched upholstery</p> <p>Durable European-styled cushions</p>

WARRANTY*

Type	Full Commercial - no usage limit
Frame	10 Years
Weights & Guide Rods	5 Years
Cables, Belts, Bearings & Parts	3 Years
Grips, Enclosures & Covers	1 Year
Upholstery	6 Months
Labor	1 Year

CLOSER LOOK

