

N956

HORIZONTAL LEG PRESS

The SportsArt Status Strength Series is our premium club line and combines sleek and modern design with world-class components and superior biomechanics to deliver unmatched quality and function to your facility.

KEY FEATURES

- Also performs as a hip sled, calf raise and hack squat
- Seat back reclines 90-180° with a smooth fingertip adjustment lever
- Shoulder pads adjust for a snug fit and varied lifting positions
- Spacious seat carriage moves smoothly via SportsArt's linear bearing system



TECHNICAL DETAILS

Unit Weight	1108.8 lbs / 504 kg
Dimensions (LxWxH)	85.4 x 59.9 x 76.8 in / 216.8 x 152.1 x 195 cm
Weight Stack	440 lbs / 200 kg
Max User Weight	500 lbs / 227 kg
Starting Weight	49.5 lbs / 22.5 kg
Features	Strengthens lower extremity Weight stack position allows for easy weight selection while on the unit Magnetized stack-fork with retracting tether makes for instant, secure selection of weights Cold rolled steel weight stacks with noise dampening Stainless steel guide rods resist rust and stay smooth Kevlar belts for quiet, smooth action and optimal tensile strength; belt contains 2200 lb (998 kg) tensile strength aircraft cables. Heavy-duty double-stitched upholstery Durable European-styled cushions

WARRANTY*

Type	Full Commercial - no usage limit
Frame	10 Years
Weights & Guide Rods	5 Years
Cables, Belts, Bearings & Parts	3 Years
Grips, Enclosures & Covers	1 Year
Upholstery	6 Months
Labor	1 Year

CLOSER LOOK

