



CT66BK2SSADALHD



32.13" x 23.63" x 22.38" (H x W x D)

24" wide ADA height ENERGY STAR certified refrigerator-freezer made in Europe with a stainless steel door and black cabinet

Highlights:

ENERGY STAR certified for guaranteed savings and a greener footprint

32" height allows easy installation under lower ADA compliant counters

5 cu.ft. of storage capacity in a perfectly sized 24" footprint

Product Features:

European refrigerator with freezer	24" wide refrigerator-freezer designed and manufactured in Europe for residential use
Large capacity	5 cu.ft. of interior storage, larger than virtually any other refrigerator-freezer in this size class
ENERGY STAR certified	Rated by the DOE to perform with more efficiency than federal standards require, saving your unit energy and you on higher utility costs
ADA Compliant height	32" height allows easy installation under lower ADA compliant counters
Slim counter height dimensions	Ideal 24" footprint for an easy fit
Freezer included	Interior .6 cu.ft. freezer compartment with reversible door
Dual evaporator	Our unique and efficient design separately cools the refrigerator while maintaining a lower temperature in the freezer compartment by utilizing two evaporators
Cycle defrost	This system utilizes user-friendly automatic defrost operation in the fresh food section and efficient manual defrost operation in the freezer compartment
Adjustable glass shelves	Rearrange your refrigerator space to accommodate all shapes and sizes or remove shelves for a simple clean-up



CT66BK2SSADALHD Specifications:

Overview	
Nominal Height	32.0" (81 cm)
Height of Cabinet	32.0" (81 cm)
Height to Hinge Cap	32.13" (82 cm)
Nominal Width	24.0" (61 cm)
Width	23.63" (60 cm)
Nominal Depth	23.0" (58 cm)
Depth	22.38" (57 cm)
Depth with Handle	24.0" (61 cm)
Depth with door at 90°	44.25" (112 cm)
Capacity	5.0 cu.ft. (142 L)
Defrost Type	Cycle
Door	Stainless Steel
Cabinet	Black
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Energy Usage/Year	330.0kWh/year
Amps	1.2
Voltage/Frequency	115 V AC/60 Hz
Weight	100.0 lbs. (45 kg)
Parts & Labor Warranty	1 Year
Compressor Warranty	5 Years
UPC	761101103396

Refrigerator-Freezer	
Door Swing	LHD
Reversible	No
Adjustable Shelves	Yes
Crisper Qty	1
Crisper Finish	Transparent
Crisper Cover	Glass
Wine Bottle Shelving	Yes
Interior Light	Yes
Refrigerator - Interior Height	18.0" (46 cm)
Refrigerator - Interior Width	21.0" (53 cm)
Refrigerator - Interior Depth	18.0" (46 cm)
Refrigerator - Capacity	4.3 cu.ft

Refrigerator - Shelf Type	Glass
Refrigerator - Shelf Qty	2
Refrigerator - Full Door Shelves	3
Refrigerator - Temperature Range	36°F to 46°F
Freezer - Interior Height	5.25" (13 cm)
Freezer - Interior Width	19.0" (48 cm)
Freezer - Interior Depth	11.5" (29 cm)
Freezer - Capacity	0.7 cu.ft
Thermostat Type	Dial
Refrigerant Type	R600a
Refrigerant Amount	0.92 oz.
High Side PSI	180.0
Low Side PSI	80.0
Level Legs	2
Compressor Step Height	5.5" (14 cm)
Compressor Step Width	21.0" (53 cm)
Compressor Step Depth	6.0" (15 cm)
Sound Level	32.6

