



CT66BK2SSRSIF



33.5" x 23.63" x 22.38" (H x W x D)

24" wide counter height ENERGY STAR certified refrigerator-freezer for recessed use, made in Europe with a panel-ready door, black cabinet, and deluxe black interior

Highlights:

- Panel-ready door lets you customize the unit for a seamless look that integrates into your kitchen
- ENERGY STAR certified for guaranteed savings and a greener footprint
- Made in Europe

Product Features:

European refrigerator with freezer	24" wide refrigerator-freezer designed and manufactured in Europe for residential use
Panel-ready door	Integrated stainless steel door frame allows you to mount full overlay panels over the door to create a custom look that can blend into cabinetry with no exposed frame (panel size: 23 5/16" W x 28 1/4" H and at least 3/4" thick; maximum weight: 10 lbs.)
Large capacity	5 cu.ft. of interior storage, larger than virtually any other refrigerator-freezer in this size class
ENERGY STAR certified	Rated by the DOE to perform with more efficiency than federal standards require, saving your unit energy and you on higher utility costs
Slim counter height dimensions for recessed or freestanding use	Ideal 24" footprint for an easy fit
Height adjustable	Adjustable legs allow you to set the height anywhere between 33.5" and 34.5" to best fit under your counter
Leg shield included	Removable cover that lets you fill the gap that can appear between the refrigerator's kickplate and floor when raising the height
Freezer included	Interior .6 cu.ft. freezer compartment with reversible door

Dual evaporator Our unique and efficient design separately cools the refrigerator while maintaining a lower temperature in the freezer compartment by utilizing two evaporators



CT66BK2SSRSIF Specifications:

Overview	
Nominal Height	34.0" (86 cm)
Height of Cabinet	33.13" (84 cm)
Height to Hinge Cap	33.5" (85 cm)
Nominal Width	24.0" (61 cm)
Width	23.63" (60 cm)
Nominal Depth	23.0" (58 cm)
Depth	22.38" (57 cm)
Depth with Handle	24.0" (61 cm)
Depth with door at 90°	44.25" (112 cm)
Capacity	5.0 cu.ft. (142 L)
Defrost Type	Cycle
Door	Panel-Ready
Cabinet	Black
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Energy Usage/Year	330.0kWh/year
Amps	1.2
Voltage/Frequency	115 V AC/60 Hz
Weight	100.0 lbs. (45 kg)
Parts & Labor Warranty	1 Year
Compressor Warranty	5 Years
UPC	761101103341
Refrigerator-Freezer	
Door Swing	RHD
Reversible	Factory Reversible
Height Adjustable	Yes
Adjustable Shelves	Yes
Crisper Qty	1
Crisper Finish	Transparent
Crisper Cover	Glass
Wine Bottle Shelving	Yes
Interior Light	Yes
Refrigerator - Interior Height	18.0" (46 cm)
Refrigerator - Interior Width	21.0" (53 cm)
Refrigerator - Interior Depth	18.0" (46 cm)
Refrigerator - Capacity	4.3 cu.ft

Refrigerator - Shelf Type	Glass
Refrigerator - Shelf Qty	2
Refrigerator - Full Door Shelves	3
Refrigerator - Temperature Range	36°F to 46°F
Freezer - Interior Height	5.25" (13 cm)
Freezer - Interior Width	19.0" (48 cm)
Freezer - Interior Depth	11.5" (29 cm)
Freezer - Capacity	0.7 cu.ft
Thermostat Type	Dial
Refrigerant Type	R600a
Refrigerant Amount	0.92 oz.
High Side PSI	180.0
Low Side PSI	80.0
Level Legs	2
Compressor Step Height	5.5" (14 cm)
Compressor Step Width	21.0" (53 cm)
Compressor Step Depth	6.0" (15 cm)
Sound Level	32.6

