



FF1DSS24



17.75" x 23.5" x 22.88" (H x W x D)

Single drawer all-refrigerator approved for residential and commercial use, built-in capable or freestanding, with digital thermostat, frost-free operation, and panel-ready stainless steel drawer with oversized front for use in 24" wide spaces

Highlights:

- Commercially approved to ETL-S to NSF-7 and UL-471 standards for commercial settings
- Flexible design allows built-in or freestanding use in 24" wide spaces
- Panel-ready drawer allows you to create a truly custom look for your space

Product Features:

Commercially approved	ETL-S listed to NSF-7 standard and meets UL-471 for use in commercial settings
Built-in capable	Front-breathing design allows you to build the drawer into cabinetry
24" wide drawer front	Note: cabinet is sized at 21.5" wide, with the oversized stainless steel front panel to cover 24" wide openings
Panel-ready drawer front	Drawer accepts an overlay panel to let you seamlessly blend the unit into an existing cabinetry design (panel dimensions: 15.6" H x 21.4" up to 24" W at 3/4" maximum thickness)
304 grade stainless steel drawer	Drawer front and interior constructed from stainless steel for added durability and easy cleanability
Frost-free operation	Minimum user maintenance with a fully no-frost operation system
Digital thermostat	Electronic controls located on the top drawer ensure easy temperature management, with an external readout of Celsius or Fahrenheit
LED lighting	Elegant LED lighting in a gentle white hue illuminates the refrigerator for an easy view of the interior
Drawer dividers	Two dividers make it simple to organize the drawer interior



FF1DSS24 Specifications:

Overview	
Nominal Height	18.0" (46 cm)
Height of Cabinet	17.75" (45 cm)
Nominal Width	24.0" (61 cm)
Width	23.5" (60 cm)
Nominal Depth	23.0" (58 cm)
Depth	22.88" (58 cm)
Depth with Handle	24.38" (62 cm)
Depth with door at 90°	36.13" (92 cm)
Capacity	1.6 cu.ft. (45 L)
Defrost Type	Frost-Free
Door	Stainless Steel/Panel-Ready
Cabinet	Black
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Sanitation	ETL-S
Energy Usage/Year	273.0kWh/year
Amps	1.0
Voltage/Frequency	115 V AC/60 Hz
Weight	63.0 lbs. (29 kg)
Parts & Labor Warranty	1 Year
Compressor Warranty	5 Years
UPC	761101081519
Refrigerator Features	
Sabbath Mode	Yes
Door Swing	Drawer
Reversible	No
Thermostat Type	Digital
Fan Type	Interior and Exterior
Refrigerant Type	R600a
Refrigerant Amount	0.78oz.
High Side PSI	270.0
Low Side PSI	105.0
Level Legs Qty	4
Interior Light	Yes
Temperature Range	36 to 43°F

Sound Level	33.3 dB
Dimensions	
Interior Height	13.0" (33 cm)
Interior Width	16.0" (41 cm)
Interior Depth	11.5" (29 cm)
Compressor Step Height	7.0" (18 cm)
Compressor Step Width	16.0" (41 cm)
Compressor Step Depth	1.0" (3 cm)

