



LX1DPNR



11.88" x 17.88" x 20.63" (H x W x D)

18" wide single drawer BeautiFridge cosmetics cooler for built-in use with panel-ready drawer front

Highlights:

Single drawer BeautiFridge cooler to elevate your self-care routine and home space

Perfectly sized to fit into bathroom fixtures, powder rooms, or vanity tables

Flexible design allows built-in or freestanding use in 18" wide spaces

Product Features:

BeautiFridge Cosmetics Refrigerator	Designed and constructed to ensure the proper storage conditions for skincare products
18" wide single drawer cooler	Slim fit allows you to elevate extra undercounter or wall space
Panel-ready	Drawer accepts an overlay panel to let you seamlessly blend the unit into an existing cabinetry or closet design (panel dimensions: 11.9" H x 17.87" W at 3/4" thickness)
Built-in capable	Designed for installation in 12" H x 18" W x 22.5" D cutouts with cross ventilation in rear
Quiet operation	Solid state cooling eliminates the typical noises and vibrations produced by compressor-based coolers
Blush pink finish	Gentle pink front in a matte finish offers a playful look for your space
304 grade stainless steel drawer	Drawer front and interior constructed from stainless steel for added durability and easy cleanability
Digital thermostat	Electronic controls located on the top drawer ensure easy temperature management, with an external readout of Celsius or Fahrenheit
Perfect chilling temperature	Designed to operate between 46 and 68°F for the ideal storage of perfumes, serums, and other skincare products



LX1DPNR Specifications:

Overview	
Nominal Height	12.0" (30 cm)
Height of Cabinet	11.88" (30 cm)
Nominal Width	18.0" (46 cm)
Width	17.88" (45 cm)
Depth	20.63" (52 cm)
Depth with Panel	21.38" (54 cm)
Capacity	0.8 cu.ft. (23 L)
Bottles	8 bottles
Defrost Type	Frost-Free
Door	Panel-Ready
Cabinet	Black
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Amps	1.0
Voltage/Frequency	115 V AC/60 Hz
Weight	45.0 lbs. (20 kg)
Parts & Labor Warranty	1 Year
UPC	761101146720
Refrigerator Features	
Sabbath Mode	Yes
Door Swing	Drawer
Thermostat Type	Digital
Fan Type	Exterior
Level Legs Qty	2
Temperature Range	46 to 68°F
Dimensions	
Interior Height	7.0" (18 cm)
Interior Width	13.63" (35 cm)
Interior Depth	12.25" (31 cm)

