

SCR23SSGLH



83.75" x 27.5" x 31" (H x W x D)

23 cu.ft. commercial reach-in refrigerator in complete stainless steel with glass door and left hand door swing

Highlights:

- Commercially listed to NSF standards
- Stainless steel interior and exterior cabinet for true durability in high traffic commercial settings
- Glass door provides a full display of stored products

Product Features:

Complete stainless steel construction	Interior and exterior are entirely constructed from stainless steel for lasting durability and easy cleanup
Glass door	Full display of the interior, with an anti-condensate door frame heater to ensure a clear view
Forced air cooling	Top-mounted commercial fan ensures rapid temperature recovery
Automatic defrost with adjustable cycle defrost	Adjustable cycle defrost operation ensures the unit avoid temperature spikes and ice buildup
Self-closing door	Closes to save energy but will remain open when the door is opened at a 90° angle for easier loading
Open door alarm	Alarm will beep 3 times if the door is left open for 30 seconds, 5 times at 60 seconds, and will sound continuously if the door is open for more than 5 minutes
Temperature alarm	Visual and audible alarms alert if the interior temperature rises or falls out of set range
Commercial grade casters	Ships with a set of casters (2 locking) for easy mobility as needed
Microprocessor control panel	Digital controls with a large LED readout in Celsius or Fahrenheit for intuitive temperature management

SCR23SSGLH Specifications:

Overview	
Nominal Height	84.0" (213 cm)
Height of Cabinet	83.75" (213 cm)
Nominal Width	28.0" (71 cm)
Width	27.5" (70 cm)
Nominal Depth	31.0" (79 cm)
Depth	31.0" (79 cm)
Depth with Handle	32.75" (83 cm)
Depth with door at 90°	56.5" (144 cm)
Capacity	23.0 cu.ft. (651 L)
Defrost Type	Automatic
Door	Glass
Cabinet	Stainless Steel
US Electrical Safety	UL
Canadian Electrical Safety	ULC
Sanitation	ETL-S
Amps	7.5
Voltage/Frequency	115 V AC/60 Hz
Weight	282.0 lbs. (128 kg)
Parts & Labor Warranty	2 Years
Compressor Warranty	5 Years
UPC	761101066776
Refrigerator Features	
Door Swing	LHD
Reversible	No
Shelf Type	Wire
Shelf Qty	4
Adjustable Shelves	Yes
Thermostat Type	Digital
Fan Type	Interior
Refrigerant Type	R290
Refrigerant Amount	2.5oz.
High Side PSI	290.0
Low Side PSI	155.0
Wheel Qty	4
Interior Light	Yes
Temperature Range	33 to 41°F
Sound Level	34.6 dB

Dimensions	
Interior Height	51.5" (131 cm)
Interior Width	23.5" (60 cm)
Interior Depth	27.0" (69 cm)

