



SINC2B115



1.88" x 11.38" x 20.5" (H x W x D)

ENERGY STAR certified 1800W 115V 12" wide 2-zone built-in induction cooktop with a jet black glass surface, touch controls, and pre-installed power cord

Highlights:

- ENERGY STAR certified for guaranteed savings and a greener performance
- 115V design with pre-installed power cord and 3-prong plug included
- Advanced safety features include automatic shutoff, overflow protection, child lock, and residual heat indicator light

Product Features:

ENERGY STAR certified	Rated by the DOE to perform with more efficiency than federal standards require, saving your unit energy and you on higher utility costs
115V 2-Burner Induction Cooktop	Smooth-top glass cooktop ideal for hotels, apartments, and other small kitchen spaces
115V operation	Designed for use with 110-120V connections
Power cord included	Pre-installed 115V NEMA 5-15P 3-pronged cord for easier setup
Induction heating	Electromagnetic heating technology where heat is generated inside your cookware, ensuring a more efficient process with less energy waste, faster heating, and a safer cooking experience
1800W operation	Rear burner can operate up to 1800W, while front burner can reach 1300W; NOTE: because this is a 120V cooktop, the max wattage is 1800W. If both burners are in use and exceed 1800W, the element you are not adjusting will automatically default to a lower power setting
Jet black glass surface	Elegant style on a smooth, jet black glass surface for a contemporary look that is easier to clean
Large rear element	8 1/4" element operates at a maximum of 1800W
Standard front element	6 1/4" 1300W front element to cover most general cooking needs



SINC2B115 Specifications:

Overview	
Nominal Height	1.88" (5 cm)
Height of Cabinet	1.88" (5 cm)
Nominal Width	12.0" (30 cm)
Width	11.38" (29 cm)
Nominal Depth	21.0" (53 cm)
Depth	20.5" (52 cm)
Cabinet	Black
US Electrical Safety	ETL
Amps	15.0
Voltage/Frequency	115 V AC/60 Hz
Weight	14.0 lbs. (6 kg)
Parts & Labor Warranty	1 Year
UPC	761101083513
Induction Cooktop	
Application	Built-in
Heating Type	Induction
Surface	Glass
Number of Elements	2
Controls	Digital
Cooking Timer	Yes
Countertop Cutout Width	10.63" (27 cm)
Countertop Cutout Depth	19.63" (50 cm)
Power Source	115V
Element #1 Size	6.25
Element #1 Wattage	1300.0
Element #2 Size	8.25
Element #2 Wattage	1800.0
Power Cord Included	Yes

