

# XLERATOReco<sup>®</sup> HAND DRYER



## ENHANCED STANDARD FEATURES



Adjustable Speed and  
Sound Control



Multi-Voltage Options:  
110-120V Or 208-277V



500 Watts  
No Heat



Externally Visible  
Service LED

**10**  
SECONDS<sup>1</sup>  
dry time

**95%**  
COST SAVINGS  
versus paper towels

**1.7**  
WATT HOURS  
energy use



# XLERATOR<sup>eco</sup>® HAND DRYER



MODELS: **XL - BW W GR C SB SI SP - ECO -H** (HEPA Filter) OPTIONS: **-1.1N** (Noise Reduction Nozzle) **-VOLTAGE** (See Chart)



**XL-BW-ECO**  
White Thermoset Resin (BMC)

TESTED TO  
**PCR**  
GUIDELINES

**DRY TIME: 10 SECONDS<sup>1</sup>**

**ENERGY PER USE: 1.7 Wh<sup>1</sup>**



Smart EPD<sup>®</sup> verifies Environmental Product Declarations (EPDs) for consistency with the LCA and conformance with global Product Category Rules (PCR) for hand dryers. UL Environment published the first global PCR for hand dryers. Third-party testing to these guidelines documents a product's environmental impact over its lifecycle. This impact is detailed in Environmental Product Declarations, enabling specifiers and buyers to make true apples-to-apples comparisons and more informed product selections. Excel Dryer received the industry's first certified EPDs.

## FEATURES & BENEFITS

- ✓ 50% Longer Life
- ✓ Industry Leading 7-Year Limited Warranty
- ✓ 95% Cost Savings Vs. Paper Towels
- ✓ Helps Qualify For The Most LEED<sup>®</sup> Credits
- ✓ No Heat Technology
- ✓ Made In USA Certified<sup>®</sup>
- ✓ A Hygienic Hand Drying Solution
- ✓ Washable Pre-Filter

## OPTIONS

- ✓ **Electrostatic HEPA (eHEPA<sup>®</sup>) Filtration System:** Removes 99.999% of viruses and 99.97% of potentially present bacteria at 0.3 microns from the airstream<sup>2</sup>.
- ✓ **1.1" Noise Reduction Nozzle:** Reduces the sound level by 9 decibels by significantly decreasing air deflection noise while only increasing dry time by approximately 3 seconds.



**XL-W-ECO**  
White Epoxy Painted



**XL-GR-ECO-H**  
Graphite Textured Painted



**XL-SP-ECO-H<sup>3</sup>**  
Custom Special Paint



**XL-SI-ECO-H<sup>4</sup>**  
Custom Special Image



**XL-C-ECO**  
Chrome Plated



**XL-SB-ECO**  
Brushed Stainless Steel

## PERFORMANCE

**ADJUSTABLE SOUND LEVEL:** 65-75 dB    **ADJUSTABLE VELOCITY:** 13,000-20,000 LFM  
**FLOW RATE:** 43-65 CFM

## DIMENSIONS

**Width** 11 3/4" (298 mm)    **Height** 12 11/16" (322 mm)    **Depth** 6 11/16" (170 mm)

## ELECTRICAL

VOLTS	AMPS	WATTS	HERTZ	
110-120V	4.3-4.5A	460-530W	50/60 Hz	
208-277V	2-2.2A	425-500W	50/60 Hz	
230V	2.2A	500W	50 Hz	

**NOTE:** Drawing 4.5 Amps or less allows for the installation of multiple XLERATOR<sup>eco</sup> units on one circuit, significantly reducing installation costs and creating a return on investment of less than one year.

## CERTIFICATIONS



## WEIGHT

**XL-BW-ECO:** 12.4 lbs. (5.62 kgs.)    **XL-SB-ECO:** 16 lbs. (7.26 kgs.)  
**XL-W-ECO, XL-GR-ECO, XL-C-ECO, XL-SI-ECO, XL-SP-ECO:** 17 lbs. (7.71 kgs.)

## ACTIVATION

**Automatic Sensor Operated**

## MOUNTING

**Surface Mounted**

## SUGGESTED MOUNTING HEIGHTS

**Men** 45" (114 cm)    **Women** 43" (109 cm)    **Accessible** 37" (94 cm)

Note: Heights measured from floor to bottom of dryer.

#40505/#40502

## ACCESSORIES

- ✓ Antimicrobial Wall Guards (#89B, #89W, #89S)
- ✓ XChanger<sup>®</sup> Paper Towel Dispenser Retrofit Kit (#40575, #40550)
- ✓ ADA-Compliant Recess Kit (#40505/#40502)



<sup>1</sup>Dry time and energy use testing performed by SGS International on standard XLERATOR Hand Dryer with 0.8" nozzle to 0.25g or less of residual moisture, pursuant to the UL Environment Global Product Category Rules (PCR) for Hand Dryers. <sup>2</sup>Based on testing performed by LMS Technologies, 2023. <sup>3</sup>Special Paint powder-coated covers are available in many colors and textures. <sup>4</sup>Exclusive digital image technology allows for the addition of company, school or team logos with any color, design or a "green message".



# TIME TO THROW IN THE TOWEL<sup>®</sup>

EXCEL DRYER INC • 1.800.255.9235 • EXCELDRYER.COM

MAY 2026

ECS26138.252.1